

## **Netcomm V300 (Router Setup).**

*Only use this guide if you have only an ADSL modem or a ADSL modem/router in “bridge” mode.*

*To find out how to bridge the modem/router you have please refer to the manufactures setup guide.*

After following this guide please follow Netcomm V300 ATA setup for instruction on how to setup the VoIP service.

Open your Web browser and type 192.168.30.1 in its address bar. You will see the login window. A default user account is created with the user name *admin* and password *admin*.



Click on WAN Setup menu item from the menu bar on the left hand side then click on WAN setup button to bring up the WAN Setup window

**WAN SETUP**

---

**Select WAN MODE :**

**Static IP address**

**DHCP mode**

**PPPoE mode**

Select PPPoE mode and then click on Next button to display the following window

**WAN SETUP**

---

**PPPoE Configuration**

User name:

Password:

Confirm Password:

Enter your Username, Password and Confirm password then click the Apply button to submit the settings.